

INSTRUCTIONS

linking armrest for **Ispra** by drake

Snap on, NO TOOLS required



position chairs & insert armlink

Place chairs side by side approximately 3 inches apart. There are 2 horizontal pins on both the left & right side of the armrest (that is the top).



slide down

Hold by the top of the armrest & slide behind the top of the two chair upper leg supports. Slide down the chairs so that when the armrest swings down it snaps into place over the "buttons" on the front of the chair.



push down to lock

You will hear the armrest snap into place.



**That's it...
Enjoy!!!**